

Installation Instructions

uridan[®] MINI TOWER for vertical drainpipe, type GVMT-2.

Installation of the uridan water free urinals is very simple. If you have earlier had water flush urinals, the drainpipe **should** be cleaned before installation of uridan urinals.

uridan[®] urinals work without water, and therefore should only be connected with \varnothing 50 mm drainpipe. Installation should be carried out by authorized plumbers.

1. Adjust the drainpipe.
2. Put the urinal at the right place, mark the holes on the floor and take the urinal away again.
3. Drill the holes for raw plugs, and insert the raw plugs.
4. Put the urinal back on place and fix the screws.
5. Insert the small PVC pipe (B) in the water lock and afterwards fill the water lock with water.
6. Insert the stainless steel cover (A).
7. Then pour 1 bottle – 0,3 litre urilock fluid over the cover.
8. Apply silicon sealant between the urinal and the floor.

The urinal is ready for use now!

Important: Never pour urilock[®] fluid before the stainless steel cover is insert.

Please give the attached cleaning instructions, uriclean and hook to the customer.

