

Installation Instructions

uridan[®] U'nic non water unisex urinal, Type GX-6.

Installation of the uridan water free urinals is very simple. If you have earlier had water flush urinals, the drainpipe **should** be cleaned before installation of uridan urinals.

uridan[®] urinals work without water, and therefore should only be connected with \varnothing 50 mm drainpipe. Installation should be carried out by authorized plumbers.

1. Install bracket (20). The urinal hangs on this bracket.
2. uridan[®] U'nic non water unisex urinal should be held against the wall and slide the urinal down to the waste outlet \varnothing 50mm.
3. Fill the water lock with water.
4. Insert the stainless steel cover (A).
5. Then pour 1 bottle – 0,3liter urilock[®] fluid over the cover.
6. Apply silicon sealant around the edge of the urinal – between the urinal and the wall & floor.

uridan[®] U'nic non water unisex urinal is ready for use now!

Important: Never pour urilock[®] fluid before the stainless steel cover is insert.

Please give the attached cleaning instructions, uriclean and hook to the customer.

