

uridan-Cleaning Instructions

Daily Cleaning

uri**CLEAN**



uridan can be cleaned very simply with the aid of uri**CLEAN**. Simply spray the urinal surface with uri**CLEAN** and the lotus effect prevents any adhesion of urine drops, causing them to simply roll off.



- » Spray uri**CLEAN** on the cover and surface.
- » Leave for a moment to react.



- » Clean by brushing circularly with a conventional brush.



- » Polish the outer and inner surface in circular motions with the uri**CLOTH** cleaning cloth.

Refilling

around every 3 months necessary

uri**LOCK**



Our patented, biodegradable blocking fluid ensures that your uridan urinal remains completely odorless, operating without the need for costly sealants or chemical additives.



- » Pour uri**LOCK** blocking fluid directly over the cover.

**NOW IN ONLY
10 SECONDS!**

uridan-Cleaning Instructions

Deep Cleaner

1 to 2 times a year
recommended

uri**STRONG**



uriSTRONG is the cleaner for very heavy and persistent dirt and deposits in sanitary areas. uriSTRONG also removes lime and calcification.

The recommended application is 1 to 2 times a year.



» Lift cover with suction device.



» Pour 100 ml uriSTRONG directly into the urinal and leave on for 5 to 30 min.



» Rinse about 5 liters of cold water and fill the waste trap completely with water.



» Insert the cover and pour uriLOCK over the cover.